



COD. HF	DESCRIÇÃO AGRUPADA	FABRICANTE	MOD. MAQ.	NUMERO
22602	CILINDRO LEVANTE LAMINA HUB. WARCO 140 (43993)	HUBER WARCO	140	43993
21526	ÊMBOLO BULDOZZER HUB. WARCO 140 (100836)	HUBER WARCO	140	100836
21530	IMPULSOR BULDOZZER HUB. WARCO 140 (100837)	HUBER WARCO	140	100837
8336	HASTE INCLIN. RODA HUB. WARCO 140 (200130)	HUBER WARCO	140	200130
8337	CAMISA INCLIN. RODA HUB. WARCO 140 (200134)	HUBER WARCO	140	200134
6966	CILINDRO INCLIN. RODA HUB. WARCO 140 (300075)	HUBER WARCO	140	300075
6967	IMPULSOR LEVANTE LAMINA HUB. WARCO 140 (412158)	HUBER WARCO	140	412158
8331	ÊMBOLO LEVANTE LAMINA HUB. WARCO 140 (412488)	HUBER WARCO	140	412488
5672	AP. GAXETA BULDOZZER HUB. WARCO 140 (412535)	HUBER WARCO	140	412535
6971	IMPULSOR ESCARIFIC. HUB. WARCO 140 (413968)	HUBER WARCO	140	413968
15886	ÊMBOLO ESCARIFIC. HUB. WARCO 140 (413970)	HUBER WARCO	140	413970
15887	CAMISA LEVANTE LAMINA HUB. WARCO 140 (420443)	HUBER WARCO	140	420443
15891	GUIA LEVANTE LAMINA HUB. WARCO 140 (420446)	HUBER WARCO	140	420446
8304	PORCA CAMISA BULDOZZER HUB. WARCO 140 (420453)	HUBER WARCO	140	420453
8305	GUIA BULDOZZER HUB. WARCO 140 (420481)	HUBER WARCO	140	420481
8307	HASTE LEVANTE LAMINA HUB. WARCO 140 (421542)	HUBER WARCO	140	421542
8344	CAMISA LAM. DESLI. HUB. WARCO 140 (421565)	HUBER WARCO	140	421565
6887	HASTE LAM. DESLI. HUB. WARCO 140 (421569)	HUBER WARCO	140	421569
6939	PORCA CAMISA ESCARIFIC. HUB. WARCO 140 (421587)	HUBER WARCO	140	421587
7021	HASTE MOÇÃO LATERAL HUB. WARCO 140 (421709)	HUBER WARCO	140	421709
7084	CAMISA MOÇÃO LATERAL HUB. WARCO 140 (421890)	HUBER WARCO	140	421890
8303	CILINDRO LAM. DESLI. HUB. WARCO 140 (430010)	HUBER WARCO	140	430010
8304	CILINDRO MOÇÃO LATERAL HUB. WARCO 140 (430190)	HUBER WARCO	140	430190
11064	AP. GAXETA ESCARIFIC. HUB. WARCO 140 (841779)	HUBER WARCO	140	841779
11065	HASTE ESCARIFIC. HUB. WARCO 140 (842241)	HUBER WARCO	140	842241
11061	GUIA ESCARIFIC. HUB. WARCO 140 (842242)	HUBER WARCO	140	842242
11062	HASTE DIREÇÃO HUB. WARCO 140 (842270)	HUBER WARCO	140	842270
11064	CILINDRO DIREÇÃO HUB. WARCO 140 (842274)	HUBER WARCO	140	842274
11066	CAMISA DIREÇÃO HUB. WARCO 140 (842275)	HUBER WARCO	140	842275
11067	CAMISA ESCARIFIC. HUB. WARCO 140 (842277)	HUBER WARCO	140	842277
11068	CAMISA BULDOZZER HUB. WARCO 140 (842348)	HUBER WARCO	140	842348
11232	HASTE BULDOZZER HUB. WARCO 140 (842349)	HUBER WARCO	140	842349
11092	CILINDRO ESCARIFIC. HUB. WARCO 140 (843201)	HUBER WARCO	140	843201
11093	CILINDRO BULDOZZER HUB. WARCO 140 (844128)	HUBER WARCO	140	844128
4675	ÊMBOLO INCLIN. RODA HUB. WARCO 140 (6100538)	HUBER WARCO	140	6100538
4842	IMPULSOR INCLIN. RODA HUB. WARCO 140 (6100539)	HUBER WARCO	140	6100539
4905	HASTE ESCARIFIC. HUB. WARCO 140 (6200061)	HUBER WARCO	140	6200061
4836	CAMISA ESCARIFIC. HUB. WARCO 140 (6200063)	HUBER WARCO	140	6200063
17704	CAMISA LAM. DESLI. HUB. WARCO 140 (6200127)	HUBER WARCO	140	6200127
17705	HASTE LAM. DESLI. HUB. WARCO 140 (6200128)	HUBER WARCO	140	6200128
4828	CILINDRO DIREÇÃO HUB. WARCO 140 (6200159)	HUBER WARCO	140	6200159
459	GUIA INCLIN. RODA HUB. WARCO 140 (6200171)	HUBER WARCO	140	6200171
501	HASTE INCLIN. RODA HUB. WARCO 140 (6200172)	HUBER WARCO	140	6200172
3119	CAMISA INCLIN. RODA HUB. WARCO 140 (6200173)	HUBER WARCO	140	6200173
1130	CAMISA BULDOZZER HUB. WARCO 140 (6200452)	HUBER WARCO	140	6200452
14062	HASTE BULDOZZER HUB. WARCO 140 (6200453)	HUBER WARCO	140	6200453
1434	CILINDRO ESCARIFIC. HUB. WARCO 140 (6300022)	HUBER WARCO	140	6300022
1435	CILINDRO LAM. DESLI. HUB. WARCO 140 (6300055)	HUBER WARCO	140	6300055
14065	CILINDRO LEVANTE LAMINA HUB. WARCO 140 (6300077)	HUBER WARCO	140	6300077



9261	CILINDRO MOÇÃO LATERAL HUB. WARCO 140 (6300085)	HUBER WARCO	140	6300085
1436	CILINDRO INCLIN. RODA HUB. WARCO 140 (6300089)	HUBER WARCO	140	6300089
14418	CILINDRO BULDOZZER HUB. WARCO 140 (6400274)	HUBER WARCO	140	6400274
11676	REPARO BULDOZZER HUB. WARCO 140 (MAIOR)	HUBER WARCO	140	MAIOR
11679	REPARO ESCARIFIC. HUB. WARCO 140 (MENOR)	HUBER WARCO	140	MENOR
4128	IMPULSOR DIREÇÃO HUB. WARCO 140M (6100173)	HUBER WARCO	140M	6100173
4362	ÊMBOLO DIREÇÃO HUB. WARCO 140M (6100175)	HUBER WARCO	140M	6100175
14818	AP. GAXETA DIREÇÃO HUB. WARCO 140M (6100179)	HUBER WARCO	140M	6100179
4534	PORCA CAMISA DIREÇÃO HUB. WARCO 140M (6200056)	HUBER WARCO	140M	6200056
5126	GUIA DIREÇÃO HUB. WARCO 140M (6200062)	HUBER WARCO	140M	6200062
19971	HASTE DIREÇÃO HUB. WARCO 140M (6200164)	HUBER WARCO	140M	6200164
458	CAMISA DIREÇÃO HUB. WARCO 140M (6200165)	HUBER WARCO	140M	6200165
9262	CILINDRO DIREÇÃO HUB. WARCO 140M (6301285)	HUBER WARCO	140M	6301285
14819	IMPULSOR MOÇÃO LATERAL HUB. WARCO 140S (6100455)	HUBER WARCO	140S	6100455
4814	ÊMBOLO MOÇÃO LATERAL HUB. WARCO 140S (6100456)	HUBER WARCO	140S	6100456
4829	AP. GAXETA MOÇÃO LATERAL HUB. WARCO 140S (6100458)	HUBER WARCO	140S	6100458
4362	IMPULSOR LEVANTE LAMINA HUB. WARCO 140S (6100460)	HUBER WARCO	140S	6100460
17697	PORCA CAMISA MOÇÃO LATERAL HUB. WARCO 140S (6200123)	HUBER WARCO	140S	6200123
17703	GUIA MOÇÃO LATERAL HUB. WARCO 140S (6200126)	HUBER WARCO	140S	6200126
17707	CAMISA LEVANTE LAMINA HUB. WARCO 140S (6200145)	HUBER WARCO	140S	6200145
17709	HASTE LEVANTE LAMINA HUB. WARCO 140S (6200147)	HUBER WARCO	140S	6200147
17711	HASTE MOÇÃO LATERAL HUB. WARCO 140S (6200157)	HUBER WARCO	140S	6200157
4827	CAMISA MOÇÃO LATERAL HUB. WARCO 140S (6200158)	HUBER WARCO	140S	6200158
1437	CILINDRO LEVANTE LAMINA HUB. WARCO 140S (6301279)	HUBER WARCO	140S	6301279
2847	CILINDRO MOÇÃO LATERAL HUB. WARCO 140S (6301282)	HUBER WARCO	140S	6301282